


X-150

Spare parts list





SPARE PARTS LIST

X-150

Pos	Description	Art.no.	Comment
1.	Fan, complete X150-600-21	199 00003	pos 2-6
2.	Hydraulic motor 11 cc	199 40011	
3.	Fan top	199 00004	
4.	Fan wheel for X150-600-21	199 00005	
5.	Sealing, 8x4x2010mm	299 00006	
6.	Fan housing	199 00007	
7.	Rubber valve 700-460	399 S30000	
8.	Clamp for rubber valve	599 79300	
9.	Bottom housing section	199 00010	
10.	Sealing strip 3400mm	199 00021	
11.	Inlet 6"	199 00018	
12.	Inlet gasket	199 00019	
13.	Filter housing	199 00022	
14.	Filter protection	299 00011	
15.	Sealing 15x10x1200mm	299 00012	
16.	Filter	299 00013	
17.	Double-acting cylinder	299 00002	
18.	Filter lid	299 00015	
19.	Air pipe	199 00016	
20.	Valve plate dia. 210mm	299 00017	
21.	Solenoid valve assy 1"	499 54045	
	Diaphragm 1"	499 54400	
22.	6-sided nipple 1"	399 75000	
23.	Control system	199 00023	
24.	Control valve 5/2	299 00001	
25.	Wear protection	199 00020	
26.	Hosing assy	199 00024	
27.	El. cable assy	199 00025	
28.	Lock 703	399 14800	
29.	Gasket lock ring dia. 300	399 53200	
30.	Gasket 300-50	399 70900	
	Gasket 300-60	399 71000	
31.	Pick-up-hood housing, 6" outlet	399 S0110	
32.	Skirt clamp	399 79200	
33.	Rubber skirt	399 07000	
34.	Suction hose 6" ID4500	399 83690	
35.	Hose clamp 6"	399 74200	
36.	Bracket plate, standard	399 S8130	
37.	Mounting pole, standard	399 S8101	
38.	Swivel ring, standard (for pole)	399 S8161	